

Calibration of 3d load cells

0. Search for / create calibrated weights. I used water bottles with a weight of 0.5 kg and 1.5 kg.

1. At the top of the file set the right parameters:

```
#define I_LOADCELL      5  
#define I_AXIS          2
```

Whereby I_LOADCELL is the load cell number and I_AXIS can have the value 0, 1, 2 for the x, y and z axis respectively.

2. Add this block to the if statement in setup():

```
else if (I_LOADCELL == %number%){  
    cal_gain[0] = 15030;  
    cal_gain[1] = 15150;  
    cal_gain[2] = 13625;  
    cal_offset[0] = -0.30231389;  
    cal_offset[1] = 0.07867452;  
    cal_offset[2] = 0.287924;  
}
```


3. First the offset will be determined:

The offset can be determined in three directions:


- | | |
|---------|--|
| Neutral | Direction of measured axis is perpendicular to gravity |
| + | Gravity exerts positive force on the measured axis. |
| - | Gravity exerts negative force on the measured axis. |

First z-axis offset in neutral and positive orientation (zn, z+) are measured:

- Set the correct settings (adjust lines of step 1) and push the code.
- Position load cell in the following manner (red arrow = direction of gravity):



z neutral



z +


- c. Type in the Serial Monitor ‘r’ (reset offset) and enter. Repeat this a few times until you have a good approximation of the offset.
- d. If necessary: type ‘p’(pause) to see the offset value.
- e. Copy the value of the offset to the spreadsheet
- g. Repeat from step 3 a in all of these orientations:




z-



x+




x-



xn, yn



y-



y+

4. Compare the neutral offset with the mean offset (mean over negative and positive direction). It should be in the same range. Pick one of them (neutral/mean) and substitute them in the cal_offset array of step 2. The offset part is now finished, let's continue with determining the gain.

5. To adjust the gain value '+' and '-' can be entered as commands in the Serial Monitor. The gain will then increase or decrease by steps of 10. The procedure for determining the gain is:

- a. Mount the plate with spacers as depicted here:




- b. Make sure the code is pushed with the right settings (step 2)

c. Determine target value. The mounted plate already exerts some weight on the load cell, so a zero value is not to be expected. Take this little weight into consideration when calibrating.

For example:

weight neutral direction without plate	:	0	kg
weight positive direction with plate	:	0.02	kg
target value with 1.5 kg weight	:	1.52	kg

- d. Attach the weight:



- e. Adjust the gain using ‘+’ and ‘-’ to reach the target value.
- f. Use ‘p’ to obtain the gain value.
- g. Repeat from step 5 b for any of the positive and negative directions (see 3 f)

Note: z in positive direction is harder to do since you have to compress the load cell. I only measured this direction with a weight of 0.5 kg. The 1.5 kg bottle couldn't be placed stable on the surface.

- 6. Compare the gains and determine the gain that you will use. Fill in the values of cal_gain in the if statement (step 2).

Note: I noticed that sometimes the gains were the same in all directions and for all weights along a certain axis. Then it seems to be reliable. However, sometimes there were quite big differences in gain. What I did in those cases was to do step 5 again but I took the other offset (neutral / mean, see step 4). Sometimes this helped a lot!
